

NOAA All-Hazards Weather Radio

MIDLAND RADIO – MODEL WR-100

Up-to-the-Minute Weather Reports and Emergency
Information

NOAA's National Weather Service
Billings, Montana

Setting Up Your Receiver

1. **Batteries:** Critical in the event of a power loss. Do not use rechargeable batteries!
2. **AC Power Adapter:** Plug the AC Power Adapter into a 110-115 Volt AC power outlet (standard house/school current). Plug AC Power Adapter into DC jack on back of the radio.
3. **Antenna:** Position telescoping antenna vertical and extend to its full length above the radio. The antenna is located on the back of the radio. If reception is poor, try moving the radio to another location in the room.
4. **Volume Adjustment:**
 - 1) Be sure the “Weather Radio” switch on the right side of radio is set to “ON.” When this switch is on, “NOAA” will appear on the display.
 - 2) Press “WEATHER/SNOOZE,” and “WEATHER” will appear on the display.
 - 3) Press the “UP” or “DOWN” arrow to select volume.
5. **Setting Radio to Alarm For Hazards**
 - 1) Make sure the “Weather Radio” switch on right side of the radio is set to “ON” and that radio is off by pressing “WEATHER/SNOOZE.”
 - 2) Press “MENU”, then the “UP” arrow until “ALT TYPE” appears, then press “SELECT.”

- 3) Press “UP” arrow until “VOICE” appears, then press “SELECT” and “MENU.”

Programming Your Receiver

Tuning to Your Local Transmitter:

- 1) Make sure the “Weather Radio” switch on right side of the radio is set to “ON” and that radio is off by pressing “WEATHER/SNOOZE.”
- 2) Press “MENU” and then the “UP” arrow until “CHANNEL” is displayed and press “SELECT.”
- 3) Press the “UP” arrow until the desired channel and frequency is displayed and you hear the broadcast of the transmitter.
- 4) Press “SELECT.”
- 5) Press “MENU” to close menus.

Entering your County Code:

- 1) Press “MENU” and then the “UP” arrow until “SAME SET” is displayed, then press “SELECT.”
- 2) Press the “UP” arrow until “SINGLE” is displayed, then press “SELECT.”
- 3) “SAME 01” is displayed, so press “SELECT.”
- 4) The 6-digit code you need to enter is [SAME CODE](#). Press the “LEFT” or “RIGHT” arrows to select the number to change and press the “UP” and “DOWN” arrows to select the desired number.
- 5) Once the desired number is selected, press “SELECT” to store your county code, and press “MENU” to close the menu mode and return to the clock.

Emergency Alert Tests

Every Wednesday, between 11:00 AM and 12:00 PM, the National Weather Service conducts a test of the emergency alert system. During the test, your radio will scroll test message information and the advisory light will turn on. If the test does not take place because of severe weather or another emergency in the area, then the test will be done on the next available non-severe or non-emergency day at the same time.

If your radio did not scroll alert information or the advisory light did not turn on, please call the National Weather Service in Billings at : **406-652-0851**

Additional Information

In addition to life saving alerts on the radio, such things as local forecasts, the 8-14 day outlook, and current conditions are also available on the radio 24 hours a day by pressing “WEATHER/SNOOZE”.